

# Setting up your Guttermaster display



Your display (Dump Bin package consists of the following.

- Main bin
- Top rack
- Bottom rack
- Guttermaster Sign
- Cable Ties
- Cable tie holders – peel and stick

## Step 1

Remove main 4 sided bin.  
Open and stand it up – legs down



## Step 2

Remove bottom rack and install.  
Angle the rack and place it above the bottom ring



## Step 4

Remove cable tie holders, peel backing and stick to 4 corners on back of sign



## Step 3

Place top rack above the second top ring



## Step 5

Attach Guttermaster sign using cable ties.

